



Description of the display and control buttons

Display elements

- Date
- Second hand
- Minute hand
- Hour hand
- Centre stop-second
- Minute counter
- $\frac{1}{10}$ second counter (hour counter after 30 minutes)

Control buttons

- Push button A
- Crown
- Push button B

Chronograph: Basic function (Start / Stop / Reset)

Example:

- Start: Press push-button A.
- Stop: to stop the timing, press push-button A once more and read the three chronograph hands: **4min / 38sec / 7/10 sec**
- Zero positioning: Press push-button B. (The three chronograph hands will be reset to their zero positions).

Chronograph: Accumulated timing

Example:

- Start: (start timing)
- Stop: (e.g. 15 min 5 sec following 1)
- Restart: (timing is resumed)
- Stop: (e.g. 13 min 5 sec following 3) = **28 min 10 sec**
(The accumulated measured time is shown)
- Reset: The three chronograph hands are returned to their zero positions.

Please note:
Following 4, the accumulation of the timing can be continued by pressing push-button A (Restart / Stop, Restart / Stop, ...)

Chronograph: Intermediate or interval timing

Example:

- Start: (start timing)
- Display interval: e.g. 10 minutes 10 seconds (timing continues in the background)
- Making up the measured time: (the 3 chronograph hands are quickly advanced to the ongoing measured time).
- Stop: (Final time is displayed)
- Reset: The 3 chronograph hands are returned to their zero position

Please note:
Following 4, further intervals or intermediates can be displayed by pressing push-button B (display interval / make up measured time, ...)

Adjusting the chronograph hands to zero position

Example:
One or several chronograph hands are not in their correct zero positions and have to be adjusted (e.g. following a battery change).

- Pull out the crown to position III (all 3 chronograph hands are in their correct or incorrect zero position).
- Keep push-buttons A and B depressed simultaneously for at least 2 seconds (the centre stop-second rotates by 360° → corrective mode is activated).
- Returning the crown to position I

Termination of the chronograph hands adjustment (can be carried out at any time).

Adjusting the centre stop second

Single step: A 1 x short
Continuous: A long

Adjusting the next hand: B

Adjusting the $\frac{1}{10}$ second counter hand (position 6h)

Single step: A 1 x short
Continuous: A long

Adjusting the next hand: B

Adjusting the minute counter hand (position 9h)

Single step: A 1 x short
Continuous: A long

Setting the time

- Pull out the crown to position III (the watch stops).
- Turn the crown until you reach the correct time 8:45.
- Push the crown back into position I.

Please note:
In order to set the time to the exact second, 4 must be pulled out when the second hand is in position 6h. Once the hour and minute hands have been set, 5 must be pushed back into position I at the exact second.

Setting the date (quick mode)

- Pull out the crown to position II (the watch continues to run).
- Turn the crown until the correct date 01 appears.
- Push the crown back into position I.

Please note:
During the date changing phase between 9 PM and 12 PM, the date must be set to the date of the following day.

An extreme acceleration in setting the date with quick mode can induce a false date indication. The synchronization is re-established by setting the date from 01 till 31 (crown in position II).

Setting the date/time following a battery change

Example:
- Date / time on the watch: 07.25 AM
- Present date / time: 04.30 PM

- Pull out the crown to position II (the watch continues to run).
- Turn the crown until yesterday's date appears 03.
- Pull out the crown to position III (the watch stops).
- Turn the crown until the correct date 04 appears.
- Continue to turn the crown until the correct time 8:30 PM appears.
- Push the crown back into position I.

Please note:
* To set your watch to the exact second, please refer to the chapter entitled 'setting the time.'
** Please observe the AM/PM clock rhythm.